


1、INTRODUCTION:	1
2、ASSEMBLY DRAWING:	1
3、ILLUMINATE:	1
4、PRECAUTION:	1
5、FEATURES:	2
6、AVAILABLE UNITS:	2
7、PANEL AND KEYPAD DEFINITION:	2
7. 1 FUNCTION SETTING:	4
7. 2 PARAMETER SETTING:	4
BACKLIGHT SETTING:	4
FILTER SETTING:	5
ZERO BAND SETTING:	5
BAND RATE SETTING:	5
HOLD TIME SETTING:	6
WEIGHT HOLD SETTING:	7
RS232 OUTPUT FORMAT SETTING:	7
EXTERNAL DEVICE SETTING	7
RS232 OUTPUT CONTENT SETTING:	8
AVAILABLE UNITS SETTING	8
INITIAL UNIT SETTING:	8
BACK TO NORMAL WEIGHING MODE:	8
8、KEYPAD ILLUMINATE:	9
BACK TO ZERO:	9
TARE:	9
PRE-TARE:	10
WEIGHING FUNCTION SWITCH:	10
SAMPLE:	11
UNITS SWITCH:	11
PRINT:	11
GROSS / NET SWITCH:	11
9、CALIBRATION	12
SINGLE POINT CALIBRATION	12
CAPACITY AND RESOLUTION SETTING	13
INTERNAL COUNT VALUE DISPLAY	14
10、ERROR MESSAGE:	14
10.1 ERROR MESSAGE	14
10.2 ERROR SHOOTING	14
11、SPECIFICATION:	14
12、INTERNAL RESOLUTION TABLE:	15
13、RS232 OUTPUT FORMAT:	15

## **1、INTRODUCTION: ---**

Thank you for your purchase of a Hengx high resolution electronic scale. This scale enables you to measure the quality and weight. The scale is easy to operate, precise, stable and with fast display reaction. It is applicable in the electronic, hardware, plastic, medicine, textile and various other industries. It is useful for packaging, inventory and various production and quality control cases.

## **2、ASSEMBLY DRAWING: ---**



## **3、INSTALLATION: ---**

- I 【1】 power switch
- I 【2】 DC power socket
- I 【3】 LOADCELL interface
- I 【4】 RS-232 standard interface

## **4、PRECAUTION: ---**

1. full charge the battery after unpacking the scale.
2. recharge the battery: when battery symbol appears on the LCD display, please plug in the power cord to charge the battery. The indicator of charge will light up in red. When it becomes green means charge completed(it takes about 8 hours to full recharge the battery)\*
3. install the equipment on a level and stable surface.
4. do not install the equipment near the air condition or a vibrating machine.
5. Please in the temperature of 0°C~ 40°C, prevent from rapid temperature changes.
6. independent AC outlet for this equipment is recommended, check the voltage before plug in.
7. warm up the equipment for 15 minutes before use.


## **5、FEATURES: ---**

1. the microprocessor in this scale features:
  - A. automatic zero point tracking function
  - B. pre-tare and tare function
  - C. max accumulation (10 sets)
  - D. accumulation value print
  - E. total accumulation print
  - F. backlight auto on
  - G. RS-232 output (optional)
  - H. Can connect with printer (optional)
2. LCD display, with 45mm digits
3. With backlight
4. ABS housing; stainless pan

## **6、AVAILABLE UNITS: ---**

1. 1 kg = 1000g
2. 1 t = 1000kg
3. 1 lb = 453.59237g
4. 1 tlt = 0.5999992kg
5. 1 tlh = 0.60479kg
6. PCS
7. %

## **7、PANEL AND KEYPAD DEFINITION : ---**




KEYPAD ILLUMINATE				
1		Print or pre-tare switch	5	
				Units switch (in pre-tare and calibration mode, press this key to add one digit)
2		In the counting mode, put samples onto the pan and input the sample quantity and press this key	6	
				Do tare while there are objects on pan( when there are no objects on pan, press ▲ ▼ to load pre-tare value and press ▼ to do pre-tare( press this key can reduce the figure)
3		Net/gross weight switch	7	
				Back to zero mode. (in pre-tare or calibration mode, press this key make cursor move to left figure)
4		For % and pcs switch ( in calibration mode, press this key to eliminate a figure)		

PANEL ILLUMINATE				
8		Recharge instruction		
9				Weight display
10		Pre-tare		11
12		Gross weight		13
				HOLD function in using
				Stable symbol


## 7、1 Function setting

KEYPAD	DEFINITION
 +	Parameter setting
 + 	Keypad testing
 +  + 	Internal Count (OFFSET) value display
 +  +  + 	Normal weighing mode
 +  +  +  + 	Single point calibration
 + 	Capacity and resolution setting
 + 	

## 7、2 Parameter setting(lineation words are initial setting)


OPERATION	LCD DISPLAY
 +  press  to switch on the machine:	

### Backlight setting

 +  press  to enter backlight setting   +  press  to set in turn  I <u>『Auto</u> - the backlight will on when there is weight on it; <u><u>oFF</u>- means the backlight is turn down; <u>ON</u>- the backlight</u> <u><u>is always be light;』</u></u>	
---	---


## Filter setting

 press ► to enter filter setting
 press ▲ to set in turn 『F1、 <u>F2</u> 、F4、F8』 (higher value, higher filter grade)




## Zero band setting

 press ► to enter into zero band setting
 press ▲ to set in turn 『d0、d1、 <u>d2</u> 、d3、d4』 (higher value, bigger range of zero band)



## Band rate setting

 press ► to enter into zero band setting.   zero band: 9600
--



## Hold time setting



press ➤ to enter into HOLD time setting



press ▲ to set in turn

I co5 (continuously hold for 5 seconds) /co10  
(continuously hold for 10 seconds) /5 (hold for 5  
seconds) /10 (hold for 10 seconds) /HO (manual) /No  
(hold closed)

1. hold: when display reaches stability, the display value will hold until the time set ends; used for animal scale, such as human being or animal's weight testing.

2. continuously hold : when display reaches stability, the display value will hold until the time set ends; if the time set doesn't end, and there is a new weight greater than before, then the greater value will be held. Used for animal scale, such as human being or animal's weight changing curve.


3. manual: when display reaches stability, the display value will be




held until press ▼ to cancel. Used for animal scales,  
such as human being or animal's weight testing

4. units switch can't be used while in HOLD mode.

For example: When choose "hold for 5 seconds", Then the weight holds for 5 seconds



For example: When choose CO10“continuously hold for 5 seconds”, Then the weight continuously hold 10 seconds.



## Weight hold setting




press ➤ to enter into weight hold setting mode



press ▲ to set in turn

- I **2/5/10/20/30/50** (bigger value, bigger range of hold)  
e.g.:SHb=30



## RS232 output format setting



press ➤ to enter into print format setting



press ▲ to set in turn

[**PrtCo**-once you choose this mode it'll print continuously、  
**PrtSt** - once you choose this mode, it'll print when the  
display is stable.、**Prt Pr-** only press PRINT key can do print.]

## External device setting



press ➤ to enter external device setting



Press ▲ to set in turn

- I **PC--** connect to computer, **SH--** connect to matrix printer, **TDP--** connect to thermal printer,  
**SCR--**connect to large screen]

## RS232 output content setting




press ► to enter into print content setting



press ▲ to set in turn.

I Pr (print) / nP (not print)



## Available units setting




press ► to enter into units setting



press ▲ to choose 5 units. when the symbol ► on LCD



points to one unit, press to set this unit closed or open. (ON/OFF switch)



## Initial unit setting



press ► to enter initial unit setting



press ▲ to choose. The unit that ► pointed to is the initial unit.



press ► to choose other parameter setting





## Back to normal weighing mode





press ◀ back to normal weighing mode

## 8、keypad illuminate: ---






### Back to zero

OPERATION	LCD DISPLAY
	
I press  :   press  :	ZERO 

### Tare :

	
I press  : I tare condition: can not work below zero(minus value ) nor above maximal capacity	NET 

## pre-tare

	
 press	
 And press <b>P.T</b> to enter pre-tare mode	
 press ▲ (press this key can increase the figure) and  ▼ (press this key can reduce the figure) and (press this key can make cursor move to left figure), load pre-tare figure in.	
 press <b>P.T</b> :   do pre-tare. (do not conflict with regulations)   when conflicts with regulations, do not implement the function	


## Weighing function switch

   press ►   for weighing function, pcs and % function switch	
--	---


## Sample

In pcs or % mode	NET 
 press <b>PRINT</b> to choose sample   <u>20</u> / 50 / 100 / 200 / 500 auto-sample while stable	NET 

## Units switch

   in weighing mode, press ▲ to switch units   Kg / ton / lb / tlt/ tlh	ZERO 
--	--

## Print




 press	
 press <b>PRINT</b> , RS232 interface outputs display value	

## GROSS/NET switch






 press <b>P.T</b> to do gross/net weight switch	
---	--

## 9、CALIBRATION:




### Single point calibration

OPERATION	LCD DISPLAY
    press <b>SET</b> and <b>PRINT</b> to switch on the machine	
   press <b>ZERO</b>	
wait	
put weights on pan    press <b>UNIT</b>	
press <b>TARE</b> ▼ press this key can increase the figure) and  ▼ press this key can reduce the figure) and  (press this key can eliminate a figure) and  (press this key make cursor move to left figure) to load relevant weight in.	
 press <b>PRINT</b>	
wait	
   press <b>SET</b>   back to normal weighing mode	

## Capacity and resolution setting(see page 15)

 press	 and ► to switch on the machine	
 press ►		
 press ▲ ~ ▼ to choose min. division	 I 1 / 2 / 5 / 10/20/50	
 press ►		
 press ▲ ~ ▼ to set decimal point position.	 I	
 press ►		
 press ▲ ~ ▼ to set max. capacity	 I	
 I press to confirm I back to normal weighing mode		

## Internal COUNT value display

 press ◀ to switch on the machine	
 press ◀	
 press ◀ again	
   press ◀   back to normal weighing mode	

## 10、ERROR MESSAGE:

### 10.1 error message:

Error message	problem
Err2	Initial zero over +/-20%
Err5	Over load (max. capacity +9e)
Err7	Min. division, decimal point position or max capacity setting wrong
Battery symbol	Low battery
LOBAT	Low voltage

### 10.2 error message shooting:

When	Error message	Trouble shooting
Switch on	Err2	Check if there is object on the pan or load cell trouble
Switch on	Battery symbol	recharge
Normal weighing operation	Err5	Check if over max capacity+9e, Err
Model setting	Err7	Setting again
Normal weighing operation	LOBAT	Plug in alternating current to switch again



## 11、Specification

LCD:	LCD display, with backlight, 6 segments, with 45mm digits
adaptor:	300mA DC12V adaptor、6V4A rechargeable battery
resolution:	1/15,000
Keypad:	ZERO、TARE、UNIT、MODE、GROSS / NET、SAMPLE、SET
units:	kg , lb ,ton ,tlt, tlh, %, PCS
function:	Gross/new weight switch、weight hold、pre-tare、filter function(4 grades)、units switch、print setting、sample、auto-average
temperature:	-10°C~40°C
RS-232:	Dual、can connect with SH-24、TDP-643 matrix printer or thermal printer, computer, large screen

## 12、Internal resolution table

Max.capacity	Internal resolution					
	1d	2d	5d	10d	20d	50d
300	1/300					
400	1/400					
500	1/500					
600	1/600	1/300				
800	1/800	1/400				
1,000	1/1000	1/500				
1,200	1/1200	1/600				
1,500	1/1500	1/750	1/300			
2,000	1/2000	1/1000	1/400			
2,500	1/2500	1/1250	1/500			
3,000	1/3000	1/1500	1/600	1/300		
4,000	1/4000	1/2000	1/800	1/400		
5,000	1/5000	1/2500	1/1000	1/500		
6,000	1/6000	1/3000	1/1200	1/600	1/300	
8,000	1/8000	1/4000	1/1600	1/800	1/400	
10,000	1/10000	1/5000	1/2000	1/1000	1/500	
12,000	1/12000	1/6000	1/2400	1/1200	1/600	
15,000	1/15000	1/7500	1/3000	1/1500	1/750	1/300
20,000	1/20000	1/10000	1/4000	1/2000	1/1000	1/400
25,000	1/25000	1/12000	1/5000	1/2500	1/1250	1/500
30,000	1/30000	1/15000	1/6000	1/3000	1/1500	1/600
40,000		1/20000	1/8000	1/4000	1/2000	1/800
50,000		1/25000	1/10000	1/5000	1/2500	1/1000
60,000		1/30000	1/12000	1/6000	1/3000	1/1200
80,000			1/16000	1/8000	1/4000	1/1600
100,000			1/20000	1/10000	1/5000	1/2000
120,000			1/24000	1/12000	1/6000	1/2400
150,000			1/30000	1/15000	1/7500	1/3000
200,000				1/20000	1/10000	1/4000
250,000				1/25000	1/12000	1/5000
300,000				1/30000	1/15000	1/6000
400,000					1/20000	1/8000
500,000					1/25000	1/10000
600,000					1/30000	1/12000
700,000						1/14000
750,000						1/15000

## 13、RS-232 output format : ---




## RS-232 serial interface

The 9PIN interface in the right back is the standard interface of RS-232, 3<sup>rd</sup> PIN is output, 5<sup>th</sup> PIN is grounded, the rest is useless.

BAUD RATE: **9600 bps** DATA BIT: **8** PARITY BIT: **N(ONE)** STOP BIT: **1** CODE: **ASCII**

BIT FORMAT:



DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-								k	g	LF	CR				
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	---	---	----	----	--	--	--	--

e.g.

**ST G.W.: 1.050 kg**

DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-									l	b	LF	CR			
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	--	---	---	----	----	--	--	--

e.g.

**ST G.W.: 1.050 lb**

DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-									T	-	J	i	n	g	LF	CR
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	--	---	---	---	---	---	---	----	----

e.g.

**ST G.W.: 1.050 T-Jing**

DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-									H	-	J	i	n	g	LF	CR
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	--	---	---	---	---	---	---	----	----

e.g.

**ST G.W.: 1.050 H-Jing**

DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-									P	C	S	LF	CR			
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	--	---	---	---	----	----	--	--	--

e.g.

**ST G.W.: 1050 PCS**

DATA FORMAT: (Prt.Co)

S/U	T	G/N	•	W	•	:	+/-									%	LF	CR					
-----	---	-----	---	---	---	---	-----	--	--	--	--	--	--	--	--	---	----	----	--	--	--	--	--

e.g.

**ST G.W.: 1050 %**

DATA FORMAT: (Prt.St Prt.Pr)

N	•	W	•	:	+/-											X	X	X	X	X	X	LF	CR
T	•	W	•	:	+/-											X	X	X	X	X	X	LF	CR
G	•	W	•	:	+/-											X	X	X	X	X	X	LF	CR

e.g.

**HAIW-516**

**N/S:XXXXXX**

**N.W.: 1.000 XX**

**T.W.: 0.000 XX**

**G.W.: 1.000 XX**