

---

# **PRECISION    BALANCE**

---

## ***USER'S MANUAL***

---

**MODEL-X 2007-V2.0**


---

---

## Contents

Fixing the Weighing Pan	-----	2
Protection Device Disassembly Steps	-----	2
Precautions	-----	2
Descriptions of Keys	-----	2
Functional Operation of Keys	-----	3
Panel Illustration	-----	3
Single Point Calibration of Weight	-----	4
Single Point Calibration of Weight when Power on	-----	5
Linearity Calibration of Weight	-----	6
Parameter Setting	-----	7
Parameter Functional Description	-----	8
Units Conversion Table	-----	10
Cross-reference Table of Full Loads	-----	10
RS-232 Serial Interface	-----	11

## Weighing Pan Fixing Steps



1. When installing the weighing pan, tighten the fixing screw in the centre of the plastic weighing pan.
2. Unscrew and remove the shipping protection screw on the side of the scale.
3. After removing the shipping protection screw on the side of the scale, fasten the shipping protection buckle.

## Protection Device Disassembly Steps

1. In the upright position, locate the shipping protection screw device on the left side of the scale.
2. Before using the scale, unscrew counterclockwise and remove the shipping protection screw.
3. Before transporting the scale, hold the shipping protection screw down inwards and tighten it clockwise.

## Precautions

1. Please pay attention to the environment when performing weight calibration on the scale. Avoid wind blow and vibration.
2. Use of wrong batteries or wrong wiring may cause danger.

## Descriptions of Keys

ON/OFF :

Power switch (on the left rear side of the scale when it's in the upright position).



The zero key for resetting the equipment, functional only when weight is within 4% of the weighing capacity.




The tare key for deducting the weight of container on the weighing pan.



The weighing function switching key to select weighing, counting and percentage modes in turn.



Weighing units switching key



In the weighing mode, the key is for switching on/off backlight; in the counting and percentage modes, the key is for sampling, by pressing which constantly, you may select sample size of 20, 50, 100, 200 or 500 in turn.



Calibration function key.

## Functional Operation of Keys


### Weighing:

Press 「ON/OFF」 key, the screen will have full display and start counting down. When the screen displays




, you can start weighing. If you need backlight, press **SMPL** key.

### Counting:




Press **MODE** key, the screen will show



. You may select sample size of 20, 50, 100, 200 or 500 in turn by pressing **SMPL** in succession.

After selection, put the sample on the weighing pan and start counting operation when you hear a beep sound.  
(Automatic averaging function is provided for simple counting)

### Percentage:



Press **MODE** key, the screen will show



. You may select sample size of 20, 50, 100, 200 or 500 in turn by pressing **SMPL** in succession. After selection, put the sample on the weighing pan and start using the percentage function when you hear a beep sound.

Notes: 1. Min. unit weight of sample  $\geq 1$  d (e.g.: unit weight of sample of 300g is at least bigger than 0.01g)

2. When weight is unstable, the




3. After warming up the machine, the **WARM UP** indicator will go off.



3. After warming up the machine, the **WARM UP** indicator will go off.

### Panel Illustration





1	gradienter	7	Tare key
2	Warming up indicator	8	Zero key
3	Calibration function key	9	Weight display window
4	Sampling/Backlight key	10	Weighing unit
5	Weighing function switch key	11	Specification
6	Unit switch key		





## Single Point Calibration of Weight

Steps	Operation	Display
Step I	 Power off while holding down MODE key, and then press 「ON/OFF」 to switch on the scale.	<b>Count</b>
Step II	 Press MODE key	<b>CAL</b>
Step III	 Press UNIT key to start zero point calibration. Make sure there is nothing on the weighing pan.	<b>Zero</b> <b>CAL -S</b>
Step IV	Please place weights of equivalent weight onto the pan  Wait for a beep sound	Place 1/3 of load <b>on 1</b> Place 2/3 of load <b>on 2</b> Place full load <b>on 3</b> <b>PASS</b>
Step V	  Press MODE key, then press SMPL key	<b>buzz</b>
Step VI	After countdown, the single point calibration is completed and the scale returns to the normal weighing mode.	<b>000 g</b>

## Single Point Calibration of Weight when Power on

Steps	Operation	Display
Step I	 Hold down CAL key	
Step II	 Then press UNIT key to start zero point calibration. Make sure there is nothing on the weighing pan.	 
Step III	Please place weights of equivalent weight onto the pan	Place 1/3 of load  Place 2/3 of load  Place full load  Wait for a beep sound 
Step IV	 Press MODE key	

## Linearity Calibration of Weight

<b>Step I</b>	 <p>Power off while holding down <b>ZERO</b> <b>TARE</b> keys, and then press 「ON/OFF」 to switch on the scale.</p>	
<b>Step II</b>	 <p>Clear the weighing pan, then press <b>TARE</b> key, (zero point calibration)</p>	
<b>Step III</b>	<p>Wait for a beep sound</p>	
<b>Step IV</b>	 <p>Place 1/3 of load on the weighing pan and press <b>TARE</b> to perform 1/3 load calibration. Wait for a beep sound.</p>	
<b>Step V</b>	 <p>Place 2/3 of load on the weighing pan and press <b>TARE</b> to perform 2/3 load calibration. Wait for a beep sound.</p>	
<b>Step VI</b>	 <p>Place full load on the weighing pan and press <b>TARE</b> to perform full load calibration. Wait for a beep sound.</p>	
<b>Step VII</b>	 <p>Clear the weighing pan, then press <b>TARE</b> key</p>	
<b>Step VIII</b>	<p>After countdown, the linearity calibration is completed and the scale returns to the normal weighing mode.</p>	

## Parameter Setting



Hold down **MODE** key, then press 「ON/OFF」 key to enter the setting mode. The screen will show

**Count**



**MODE key:** To switch functions; **UNIT key:** To enter or exit function setting selection; **SMPL key:** To end setting.

**LCD Display**



**Function**



**Selection**



**Selection**



**Page**

**MODE key:**

**UNIT key:**

**SMPL key:**

**Count**

Internal value display

Item 1,  
Page

**CAL**

Single point  
auto calibration

Page 4

**unit**

Weight unit  
selection  
g, ct, lb, oz, ozt  
g, ct, lb, GN, dwt  
g, ct, lb, ozt, tl.j  
g, ct, lb, oz, tl.T  
g, ct, lb, g/m<sup>2</sup>, oz/yd<sup>2</sup>  
g, ct, lb, XX, XX

For application in Europe, America and China  
For application in Britain  
For application in Hong Kong  
For application in Taiwan  
For plaiting purpose  
For other purposes

ON/OFF

Item 2,  
Page 8

**init**

Initial weight  
unit selection  
g, ct, lb, oz, dr, GN, ozt, dwt, MM, tl.j, tl.T, tl.H, t, oz/yd<sup>2</sup>, g/m<sup>2</sup>  
Setting according to the specific applications in various regions

Item 3,  
Page 8

**bAud**

transfers rate  
selection

9600

Item 4,  
Page 8

**zero**

Auto zero  
range selection

d0/1/2/3/4/5

Item 5,  
Page 9

**F IL**

filter selection

Fil1/2/4/8

Item 6,  
Page 9

**Light**

Backlight  
selection

onoFF/oFF/ON

Item 7,  
Page 9

**Print**

Printing mode  
selection

Pr-St/Co

Item 8,  
Page 9

**Pr Fu**

External device

PC ( computer ) / SH-24(matrix printer)/



large screen

Item 9,  
Page 9

dW-P

Display range

Zero/0/1/2/3/4/5

Item 10,  
Page 10

## Parameter Function Description

Count



1. When the screen shows press the **UNIT** key, the current internal value will be displayed. Press **UNIT** key to return to the display .

unit



2. When the screen shows , press **UNIT** key to enter into unit selection mode, the screen will show or “on” means to use the current unit displayed,

“off” means not to use the current unit displayed. Press **SIMPL** to switch between ON and OFF [to use the unit



displayed select “on”, if you do not require the unit displayed select “off”]. Press **UNIT** to select from 5 kinds of



unit

weighing units, after selecting the unit required, press **MODE** to return to the display .

in itu



3. When the screen shows , press **UNIT** to enter initial unit selection mode. LCD display

in itu <sup>g</sup>



means the initial unit is g, press **UNIT** to switch the unit required, then Press **MODE** key

in itu

to return to the display .

bAud



4. When the screen shows , press **UNIT** to enter the RS-232 transfers Rate selection. LCD








9600



display represents the RS-232 transfers rate. Press **MODE** key to return to the display

bAud

. 9600 .

5. When the screen shows  , press  to enter auto zero range selection. LCD display  represents the auto zero range. Press  to select the desired auto zero range,  then press **MODE** to return to the display  . *『d0 · 1 · 2 · 3 · 4 · 5』* (The higher the value is, the wider auto zero range is.)
6. When the screen shows  , press  to enter filter setting mode. LCD display  means the filter lever. Press  to select the desired filter level and press **MODE** key  to return to the display  . *『Fil1 · 2 · 4 · 8』* (The higher the value is, the higher the filter level is.)
7. When the screen shows  , press  to enter backlight setting mode. The screen shows  . onoff represents the auto backlight setting. Press  to select the desired backlight setting and press **MODE** key to return to the display  . *『onoff- means auto-backlight, off- means backlight off, ON- means backlight on』*
8. When the screen shows  , press  to enter printing mode selection. LCD display  represents the printing mode. Press  to select the desired printing mode and press  **MODE** key to return to the display  . *『Pr-Co- means continuous output, Pr-St - means stable output』*

9. When the screen shows  , press **UNIT** to enter external device selection mode. LCD display  represents external device. Press **UNIT** to select the desired external device, then press **MODE** key to return to the display  . *『-PC-- external PC, SH-24 - external dot matrix mini printer』*

10. When the screen shows  , press **UNIT** to enter display range selection mode. LCD display  represents display range. Press **UNIT** to select the desired external device, then press **MODE** key to return to the display  . *『Zero0 · 1 · 2 · 3 · 4 · 5』* (means weight displayed when the weight exceeds the division)

11. Before entering function setting, press **SIMPL** to end function setting and return to normal weighing mode. Press the **MODE** key continuously to select function setting modes.

## Units Conversion Table

1 ct	[MET.CARAT]	=0.1999694	g
1 lb	[AVORIRDUPOIS POUND]	=453.59237	g
1 oz	[AVORIRDUPOIS OUNCE]	=28.349523125	g
1 dr	[AVOIRDUPOIS DRAM]	=1.7718451	g
1 GN	[GRAIN](U.K)	=0.06479891	g
1 ozt	[TROY OUNCE]	=31.1034768	g
1 dwt	[PENNY WEIGHT]	=1.55517384	g
1 MM	[MOMME] (JPN)	=3.749996	g
1 tl.j	[HONG KONG JEWELRY TAEL]	=37.4290018	g
1 tl.T	[TAEL](TWN)	=37.49995	g
1 tl.H	[HONG KONG TAEL]	=37.799375	g
1 t	[TOLA] (INDIA)	=11.6638038	g
1 oz/yd <sup>2</sup>		=0.33898306	g
1 g/m <sup>2</sup>		=0.01	g

## Cross-reference Table of Full Loads

CAP	150	300	600	1500	3000
Gram	150X0.005/002	300×0.01/0.005	600×0.02/0.01	1500×0.05/0.02	3000×0.1/0.05
Carat	750.34X0.02	1500.70X0.05	3001.36X0.1	7503.4X0.2	15007.0X0.5
Pound(Avoir)	0.33080X0.00002	0.66160X0.00005	1.323X0.0001	3.3080X0.0002	6.6160X0.0005
Ounce(Avoir)	5.2926X0.0002	10.5855X0.0005	21.171X0.001	52.926X0.002	105.855X0.005
Dram(Avoir)	84.685X0.005	169.37X0.01	338.72X0.02	846.85X0.05	1693.7X0.1
Grain	2315.5X0.1	4631.0X0.2	9262.0X0.5	23155X1	46310X2
Ounce(Troy)	4.8240X0.0002	9.6480X0.0005	19.296X0.001	48.240X0.002	96.480X0.005
Penny weight	96.480X0.005	192.96X0.01	385.92X0.02	964.80X0.05	1929.6X0.1
Momme	40.012X0.002	80.025X0.005	160.05X0.01	400.12X0.02	800.25X0.05
Tael (HK Jewelry)	4.0088X0.0002	8.0175X0.0005	16.035X0.001	40.088X0.002	80.175X0.005
Tael (Taiwan)	4.0012X0.0002	8.0025X0.0005	16.005X0.001	40.012X0.002	80.025X0.005
Tael (Hong Kong)	3.9696X0.0002	7.9390X0.0005	15.878X0.001	39.696X0.002	79.390X0.005
Tola (India)	12.865X0.0005	25.728X0.001	51.456X0.002	128.640X0.005	257.28X0.01
oz/yd <sup>2</sup>	442.49X0.01	884.99X0.01	1770.27 X0.01		
g/m <sup>2</sup>	15000.5 X0.5	30000 X1	60000 X1		



Note: Full Load = Capacity + (Readabilityx9)

## RS-232 Serial Interface

The 9PIN connector at the right back is a RS-232 standard interface. Pin 3 is for output, Pin 5 is for grounding and the rest have no functions.

BAUD RATE : **9600 bps**      DATA BIT : **8**      PARITY BIT : **N (NONE)**      STOP BIT : **1**      CODE : **ASCII**

BIT FORMAT :



DATA FORMAT :

S/U	T		G/N	W		+/-	D1	D2	D3	D4	D5	D6		U1	U2	U3	U4	U5	LF	CR
SP			SP			WEIGHT					SP			UNIT						

ST : **STABLE**

UT : **UNSTABLE**

GW : **GROSS WEIGHT**

SP : **SPACE**

NW : **NET WEIGHT**

D1~D6 : **WEIGHT**

U1~U5 : **UNIT**

Examples: ST GW + 150.00 g  
UT NW - 80.00 ct .....



2007/5/22